

調光器負荷名称表

調光器盤					
No. 1	No. 2	No. 3	No. 4	No. 5	No. 6
MUZ-604I	MUZ-308I	MUZ-308I	MUZ-308I	MUZ-308I	MUZ-604I
MUZ-604I	MUZ-308I	MUZ-308I	MUZ-308I	MUZ-308I	MUZ-604I
MUZ-604I	MUZ-308I	MUZ-308I	MUZ-308I	MUZ-308I	MUZ-604I
ND回路	MUZ-308I	MUZ-308I	MUZ-308I	MUZ-308I	MUZ-604I
ND回路	MUZ-308I	MUZ-308I	MUZ-308I	MUZ-604I	F-7
MUZ-308I	MUZ-308I	MUZ-308I	MUZ-308I	MUZ-604I	TBK-112

No. 1								
負荷No.相	1R	2S	3T	4R	5S	6T	7R	8S
負荷名称	客席1	客席2	客席3	客席4				
	9T	10R	11S	12T	13R	14S	15T	16R
	客席5	客席6	客席7	客席8				
	17S	18T	19R	20S	21T	22R	23S	24T
	客席9	客席10						
	25R	26S	27T	28R	29S	30T	31R	32S
	NDCL1	NDCL2	NDFS上1	NDFS上2				
	33T	34R	35S	36T	37R	38S	39T	40R
	NDFS下1	NDFS下2						
	41S	42T	43R	44S	45T	46R	47S	48T
	1B上下1	1B上下2	1B上下3	1B上下4	1B中1	1B中2	1B中3	1B中4

No. 2								
負荷No.相	49R	50S	51T	52R	53S	54T	55R	56S
負荷名称	1SL1	1SL2	1SL3	1SL4	1SL5	1SL6	1SL7	1SL8
	57T	58R	59S	60T	61R	62S	63T	64R
	1SL9	1SL10	1SL11	1SL12	1SL13	1SL14	1SL15	1SL16
	65S	66T	67R	68S	69T	70R	71S	72T
	1SL17	1SL18	1SL19	1S20	2B上下1	2B上下2	2B上下3	2B上下4
	73R	74S	75T	76R	77S	78T	79R	80S
	2B中1	2B中2	2B中3	2B中4	2SL1	2SL2	2SL3	2SL4
	81T	82R	83S	84T	85R	86S	87T	88R
	2SL5	2SL6	2SL7	2SL8	2SL9	2SL10	2SL11	2SL12
	89S	90T	91R	92S	93T	94R	95S	96T
	2S13	2S14	2S15	2S16	2S17	2S18	2SL19	2SL20

No. 3								
負荷No.相	97R	98S	99T	100R	101S	102T	103R	104S
負荷名称	3S1	3S2	3S3	3S4	3S5	3S6	3S7	3S8
	105T	106R	107S	108T	109R	110S	111T	112R
	3S9	3S10	3S11	3S12	3S13	3S14	3S15	3S16
	113S	114T	115R	116S	117T	118R	119S	120T
	3S17	3S18	3S19	3S20	1PS1	1PS2	1PS3	1PS4
	121R	122S	123T	124R	125S	126T	127R	128S
	1PS5	1PS6	1PS7	1PS8	1PS9	1PS10	1PS11	1PS12
	129T	130R	131S	132T	133R	134S	135T	136R
	2PS1	2PS2	2PS3	2PS4	2PS5	2PS6	2PS7	2PS8
	137S	138T	139R	140S	141T	142R	143S	144T
	2PS9	2PS10	2PS11	2PS12	FS上1	FS上2	FS上3	FS上4

No. 4								
負荷No.相	145R	146S	147T	148R	149S	150T	151R	152S
負荷名称	FS上5	FS上6	FS上7	FS上8	FS上9	FS上10	FST1	FST2
	153T	154R	155S	156T	157R	158S	159T	160R
	FST3	FST4	FST5	FST6	FST7	FST8	FST9	FST10
	161S	162T	163R	164S	165T	166R	167S	168T
	FC上1	FC上2	FC上3	FC上4	FC上5	FC上6	FC上7	FC上8
	169R	170S	171T	172R	173S	174T	175R	176S
	FC上9	FC上10	FC上11	FC上12	FC上13	FC上14	FC上15	FC上16
	177T	178R	179S	180T	181R	182S	183T	184R
	FC上17	FC上18	FC上19	FC上20	FCT1	FCT2	FCT3	FCT4
	185S	186T	187R	188S	189T	190R	191S	192T
	FCT5	FCT6	FCT7	FCT8	FCT9	FCT10	FCT11	FCT12

No. 5								
負荷No.相	193R	194S	195T	196R	197S	198T	199R	200S
負荷名称	FCT13	FCT14	FCT15	FCT16	FCT17	FCT18	FCT19	FCT20
	201T	202R	203S	204T	205R	206S	207T	208R
	FC奥1	FC奥2	FC奥3	FC奥4	FC奥5	FC奥6	FC奥7	FC奥8
	209S	210T	211R	212S	213T	214R	215S	216T
	LH上1	LH上2	LH上3	LH上4	LH下1	LH下2	LH下3	LH下4
	217R	218S	219T	220R	221S	222T	223R	224S
	OPC1	OPC2	OPC3	OPC4	OPC5			
	225T	226R	227S	228T	229R	230S	231T	232R
	UH上下1	UH上下2	UH上下3	UH上下4				
	233S	234T	235R	236S	237T	238R	239S	240T
	UH中1	UH中2	UH中3	UH中4				

No. 6								
負荷No.相	241R	242S	243T	244R	245S	246T	247R	248S
負荷名称	CL1	CL2	CL3	CL4				
	249T	250R	251S	252T	253R	254S	255T	256R
	CL5	CL6	CL7	CL8				
	257S	258T	259R	260S	261T	262R	263S	264T
	CL9	CL10	CL11	CL12				
	265R	266S	267T	268R	269S	270T	271R	272S
	FC上21	FCT21						

: 作業灯切替負荷
 : 天反/サス切替負荷
 : ND回路

調光器名称	客席分岐名称	容量	操作	
客席1	客席1-1	1250	客席DL	1
	客席1-2	1000	客席DL	2
	客席1-3	1250	客席DL	3
客席2	客席2-1	500	客席DL	4
	客席2-2	1000	客席DL	5
	客席2-3	1000	客席DL	6
	客席2-4	1000	客席DL	7
客席3	客席3-1	1000	客席DL	8
	客席3-2	1000	客席DL	9
	客席3-3	750	客席DL	10
	客席3-4	500	客席DL	11
客席4	客席4-1	1000	客席DL	17
	客席4-2	1000	客席DL	18
	客席4-3	1250	客席DL	19
	客席4-4	750	客席DL	20
客席5	客席4-5	750	客席DL	21
	客席5-1	700	客席BL	22
	客席5-2	800	客席BL	23
	客席5-3	700	客席BL	29
客席6	客席5-4	1450	客席BL	30
	客席6-1	1000	客席DL	15
	客席6-2	1000	客席DL	16
	客席6-3	1250	客席DL	28
客席7	予備			
	客席7-1	1300	客席BL	24
	客席7-2	1400	客席BL	25
	客席7-3	1300	客席BL	26
客席8	客席7-4	1400	客席BL	27
	客席8-1	1300	客席DL	31
	客席8-2	1200	客席DL	32
	予備			
客席9	予備			
	客席9-1	750	客席DL	33
	客席9-2	650	客席DL	34
	予備			
客席10	予備			
	客席10-1	1000	客席DL	12
	客席10-2	1000	客席DL	13
	客席10-3	1250	客席DL	14

客席ブレーカーはR-MCCB 1P 30AF/20AT